




Microcellular Elastomer Polyurethane (MEP)

MAZDA

<p>D14UA00E</p> <p>B25D 28 111-U</p> <p>323 SEDAN (1995-2000)</p> <p>Shock Absorber Bumper (RE)</p>  <p>B : 1 / C : 55 pcs.</p>	<p>D14UA00F</p> <p>C100 34 111A-U</p> <p>323 SEDAN (1995-2000)</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 70 pcs.</p>
<p>D14U64E</p> <p>GA2A 28 111-U</p> <p>CRONOS</p> <p>Shock Absorber Bumper (RE)</p>  <p>B : 2 / C : 110 pcs.</p>	<p>D14U64F</p> <p>GA2A 34 111-U</p> <p>CRONOS</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 110 pcs.</p>
<p>D14UMZ3F</p> <p>BP4K 34 111B-U</p> <p>MAZDA3</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 70 pcs.</p>	
<p>D14UT20E</p> <p>E112 28 1A0-U</p> <p>TRIBUTE, ESCAPE</p> <p>Shock Absorber Bumper (RE)</p>  <p>B : 2 / C : 50 pcs.</p>	<p>D14UT20F</p> <p>E112 34 111B-U</p> <p>TRIBUTE, ESCAPE</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 70 pcs.</p>
<p>D14UCX12F</p> <p>KD35 34 111-U</p> <p>CX5 (2012)</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 50 pcs.</p>	
<p>D14UM313F0</p> <p>BPH4 34 111A-U</p> <p>MAZDA3 (2013)</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 70 pcs.</p>	<p>D14UMZ20F</p> <p>D651 34 111A-U</p> <p>MAZDA2, FIESTA</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 70 pcs.</p>

NISSAN

<p>N14U32FZ</p> <p>54052-4M400-U</p> <p>NEO, N16</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 70 pcs.</p>	
---	--



Microcellular Elastomer Polyurethane (MEP)









HONDA

<p>O14U090E</p> <p>52722-SM4-961-U</p> <p>ACCORD (1990-1993)</p> <p>Shock Absorber Bumper (RE)</p>  <p>B : 2 / C : 70 pcs.</p>	<p>O14U090F</p> <p>51722-SM4-003-U</p> <p>ACCORD (1990)</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 70 pcs.</p>
<p>O14U094E</p> <p>52722-SM4-013-U</p> <p>ACCORD (1994-1998)</p> <p>Shock Absorber Bumper (RE)</p>  <p>B : 2 / C : 70 pcs.</p>	<p>O14U094F</p> <p>51722-SV4-004-U</p> <p>ACCORD (1994)</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 70 pcs.</p>
<p>O14U292E</p> <p>52722-SR3-003-U</p> <p>CIVIC (1992)</p> <p>Shock Absorber Bumper (RE)</p>  <p>B : 2 / C : 70 pcs.</p>	<p>O14U292F</p> <p>51722-SS0-004-U</p> <p>CIVIC (1992-1996) PRELUDE</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 110 pcs.</p>
<p>O14U2001</p> <p>52722-S5A-004-U</p> <p>CIVIC (2001)</p> <p>Shock Absorber Bumper (RE)</p>  <p>B : 2 / C : 110 pcs.</p>	<p>O14U296E</p> <p>52722-SN4-003-U</p> <p>CIVIC (1996)</p> <p>Shock Absorber Bumper (RE)</p>  <p>B : 2 / C : 110 pcs.</p>
<p>O14U496E</p> <p>52722-SS0-003-U</p> <p>CRV (1996)</p> <p>Shock Absorber Bumper (RE)</p>  <p>B : 2 / C : 70 pcs.</p>	<p>O14U402</p> <p>52722-S9A-014-U</p> <p>CRV (2002)</p> <p>Shock Absorber Bumper (RE)</p>  <p>B : 2 / C : 70 pcs.</p>
<p>O14U003E</p> <p>52722-SDA-A01-U</p> <p>ACCORD (2003)</p> <p>Shock Absorber Bumper (RE)</p>  <p>B : 2 / C : 70 pcs.</p>	<p>O14U40F</p> <p>51722-S10-004-U</p> <p>CRV (1996)</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 110 pcs.</p>
<p>O14U206F</p> <p>51722-SNA-904-U</p> <p>CIVIC (2006)</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 70 pcs.</p>	<p>O14U212F0</p> <p>51722-TS6-H01-U</p> <p>CIVIC (2012)</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 70 pcs.</p>









Microcellular Elastomer Polyurethane (MEP)















HONDA

<p>O14U304F</p> <p>51722-TF0-014-U</p> <p>CITY, JAZZ (2009)</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 70 pcs.</p>	<p>O14U311F</p> <p>51722-TG1-T01-U</p> <p>BRIO, AMAZE (2011)</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 70 pcs.</p>
<p>O14U314F</p> <p>51722-T5A-J02-U</p> <p>CITY (2014), JAZZ (2015)</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 70 pcs.</p>	<p>O14U4070F</p> <p>51722-SWE-T01-U</p> <p>CRV (2007-2011)</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 50 pcs.</p>
<p>O14U407E</p> <p>52722-SWA-A01-U</p> <p>CRV (2007-2011)</p> <p>Shock Absorber Bumper (RE)</p>  <p>B : 2 / C : 110 pcs.</p>	<p>O14U414E1</p> <p>52722-T0A-A01-U</p> <p>CRV (2014)</p> <p>Shock Absorber Bumper (RE)</p>  <p>B : 2 / C : 110 pcs.</p>
<p>O14U515F</p> <p>51722-T8N-T01-U</p> <p>HR-V (2015)</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 70 pcs.</p>	<p>O14U608F</p> <p>51722-SAA-E02-U</p> <p>FREED</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 70 pcs.</p>

MITSUBISHI

<p>M14U06E0</p> <p>MB338684-U</p> <p>E12, E15, E33</p> <p>Shock Absorber Bumper (RE)</p>  <p>B : 2 / C : 70 pcs.</p>	<p>M14U02F</p> <p>MB303069-U</p> <p>C12, CB1, CB2</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 70 pcs.</p>
<p>M14U28E0</p> <p>MB809285-U</p> <p>CK, CB</p> <p>Shock Absorber Bumper (RE)</p>  <p>B : 2 / C : 70 pcs.</p>	<p>M14U06F</p> <p>MB349347-U</p> <p>E12, E15, E33, E54</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 110 pcs.</p>
<p>M14UNA4E</p> <p>4060A047-U</p> <p>SPACE WAGON NA4, XPANDER (2018) 300 NC1W</p> <p>Shock Absorber Bumper (RE)</p>  <p>B : 2 / C : 70 pcs.</p>	<p>M14UPG4E</p> <p>MR418018-U</p> <p>PAJERO SPORT</p> <p>Shock Absorber Bumper (RE)</p>  <p>B : 2 / C : 24 pcs.</p>



**Microcellular Elastomer Polyurethane (MEP)****TOYOTA**

<p>T14U07F</p> <p>48331-20040-U</p> <p>ST150, ST171</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 110 pcs.</p>	<p>T14U08E</p> <p>48341-20120-U</p> <p>ST171</p> <p>Shock Absorber Bumper (RE)</p>  <p>B : 2 / C : 70 pcs.</p>
<p>T14U28E</p> <p>48341-12130-U</p> <p>AE101, EE90</p> <p>Shock Absorber Bumper (RE)</p>  <p>B : 2 / C : 70 pcs.</p>	<p>T14U29E</p> <p>48341-12120-U</p> <p>AE101</p> <p>Shock Absorber Bumper (RE)</p>  <p>B : 2 / C : 70 pcs.</p>
<p>T14U29F</p> <p>48331-12120-U</p> <p>AE101, AT171, AT190, AT191</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 110 pcs.</p>	<p>T14UE121F</p> <p>48331-12210-U</p> <p>ALTIS ZZE121, ZZE122</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 70 pcs.</p>
<p>T14UE121E</p> <p>48341-47010-U</p> <p>ALTIS ZZE121, ZZE122</p> <p>Shock Absorber Bumper (RE)</p>  <p>B : 2 / C : 110 pcs.</p>	<p>T14UC03F</p> <p>48331-33020-U</p> <p>CAMRY SXV10, SXV20</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 70 pcs.</p>
<p>T14UW11E</p> <p>48341-32052-U</p> <p>Shock Absorber Bumper (RE)</p>  <p>B : 2 / C : 70 pcs.</p>	<p>T14UW11F</p> <p>48331-68020-U</p> <p>WISH</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 50 pcs.</p>
<p>T14UW11E</p> <p>48341-32100-U</p> <p>WISH</p> <p>Shock Absorber Bumper (RE)</p>  <p>B : 2 / C : 110 pcs.</p>	<p>T14UC04F</p> <p>48331-33031-U</p> <p>CAMRY ACV30, ACV40</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 50 pcs.</p>
<p>T14USV41F</p> <p>48331-32090-U</p> <p>SV41</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 70 pcs.</p>	<p>T14UNC93F</p> <p>48331-52080-U, 52100-U</p> <p>VIOS NCP93, YARIS NCP91</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 70 pcs.</p>





Microcellular Elastomer Polyurethane (MEP)





CHEVROLET

<p>C14U0P0E</p> <p>96403109-U</p> <p>CHEVROLET OPTRA</p> <p>Shock Absorber Bumper (RE)</p>		<p>C14U0P0F</p> <p>96549925-U</p> <p>CHEVROLET OPTRA</p> <p>Shock Absorber Bumper (FR)</p>	
	B : 2 / C : 70 pcs.		B : 2 / C : 110 pcs.




BENZ

<p>614U0100</p> <p>201-323-2044-U</p> <p>W124</p> <p>Shock Absorber Bumper (FR)</p>		<p>614U030F</p> <p>1233-230-544-U</p> <p>W123</p> <p>Shock Absorber Bumper (FR)</p>	
	B : 2 / C : 50 pcs.		B : 2 / C : 70 pcs.

BMW

<p>B14UE36E</p> <p>3353-1136-395-U</p> <p>E36</p> <p>Shock Absorber Bumper (RE)</p>		<p>B14UE34E</p> <p>3353-1135-624-U</p> <p>E34</p> <p>Shock Absorber Bumper (RE)</p>	
	B : 2 / C : 50 pcs.		B : 2 / C : 50 pcs.
<p>B14UE30F</p> <p>3133-1124-449-U</p> <p>E30, E34, E36</p> <p>Shock Absorber Bumper (FR)</p>		<p>B14UE30E</p> <p>3133-1124-573-U</p> <p>E30</p> <p>Shock Absorber Bumper (RE)</p>	
	B : 2 / C : 50 pcs.		B : 2 / C : 70 pcs.

VOLK SWAGEN

<p>W14U0100E</p> <p>191 512 131B-U</p> <p>VENTO VGP96</p> <p>Shock Absorber Bumper (RE)</p>		<p>W14U0100F</p> <p>357 412 303-U</p> <p>VENTO VGP96</p> <p>Shock Absorber Bumper (FR)</p>	
	B : 2 / C : 50 pcs.		B : 2 / C : 70 pcs.
<p>W14U02TLE</p> <p>333 512 131B-U</p> <p>VENTO VGP96 (PASSAT, TL)</p> <p>Shock Absorber Bumper (RE)</p>			
	B : 2 / C : 70 pcs.		